


Fabric Pop up


INSTRUCTION SHEET



How to attach or replace graphics in your Fabric Pop up


WARNING!

To avoid damage, ALL hooks must be disconnected before collapsing the frame.




1

Assemble frame and lay flat on its back.
Remove existing graphic.




2

Starting at one corner, attach velcro on the graphic to velcro on the frame.
Note: Velcro on the graphic should extend approx 1/4" beyond velcro on the frame (It should not be flush).
Note: Velcro should not be flush.



3

Work in a continuous direction around the frame
attach the rest of the graphic.



4

If needed, adjust velcro for tight fit.